

# Electronic Plug-in Timer TDT7

Liquid Crystal Display (LCD) and integrated circuit are used in this digital timer. The timer has a large screen display, multi-functions, and is easy to use under heavy loads.

The digital timer display the present time accurately. It can control eight groups of on/off switches. It can provide a random timing output when required. There are also many combinations, such as hourly, daily, weekly, group of the week, for the timer on and off selection.


## 1. Setting of time

Before using the timer, present time must be set.

- **1.1** Press "CLOCK" and "HOUR" at the same time to set the hour.
- 1.2 Press "CLOCK" and "MIN" at the same time to set the minute.
- **1.3** Press "CLOCK" and "WEEK" at the same time to set the week.

## 2. Setting of timer program

- **2.1** Press "**PROG**" for the setting mode. The display shows "**1 ON**".
- **2.2** Press "**HOUR**" 、"**MIN**" and "**WEEK**" to set the hour and minute as well the day of the week for the timer on.
- **2.3** Press "**PROG**" again to set off time. The display shows "**1 OFF**".
- **2.4** Repeat 2.2 above for the off time.
- **2.5** Press "**PROG**" again to enter into the second on/off mode.
- **2.6** Repeat 2.1 to 2.4 for setting the timer on/off.



### 3. Combination weekly setting

- **3.1** During the timer on/off setting mode, press "**WEEK**" once. The display will show **Mo, Tu, We, Th, Fr, Sa, Su**. This means it is a daily on/off setting.
- **3.2** Press "**WEEK**" again, the week day will show. Set the required week day. In this setting the timer will only work in the set week day.



# **Operating Manual**

Johannesburg Tel: (011) 879-6600 Fax: (011) 879-6603 Cape Town Tel: (021) 594-7100 Fax: (021) 594 7130 Durban Tel: (031) 492-0481 Fax: (031) 569-9909 Port Elizabeth Tel: (041) 408-2400 Fax: (041) 453-0336











- **3.3** After the display shows **Su**, pushing "**WEEK**" will show **Mo, Tu, We, Th, Fr**. The timer will provide only the settings for the working day of the week.
- **3.4** Press "**WEEK**" again, the display will show **Sa, Su**. That means the timer provides only the setting for the weekend.
- **3.5** Press "**WEEK**" again, the display will show the whole week except Sunday. That means the timer will work on all week days except Sunday.
- **3.6** Press "WEEK" again, the display will show Mo, We, Fr. The timer will work during these 3 days.
- **3.7** Press "WEEK" again, the display will show **Tu, Th, Sa.** The timer will work during these 3 days.
- **3.8** Press "WEEK" again, the display will show Mo, Tu, We. The timer will work during these 3 days.
- **3.9** Press "WEEK" again, the display will show Th, Fr, Sa. The timer will work during these 3 days.

Press "R" to cancel the week day settings. Press it again to go back to the previous week day.

### 4. Timer ON/OFF turn on or turn off mode

- **4.1** Press "ON/AUTO/OFF". There is an indicator in the display showing "ON", "AUTO" or "OFF" mode.
- **4.2** Press the indicator to "ON". The timer will provide a permanent 'Switch On' output.
- **4.3** Press the indicator to "AUTO". The timer will be switched on and switched off during the set time.
- **4.4** Press the indicator to "**OFF**". The timer is turned off.

#### 5. Special functions

5.1 Press "**WEEK**" and "**HOUR**" at the same time. The display will show '**0**' on the right hand side. This means the On timing and Off timing will be extended from 2 minutes to 32 minutes randomly.

## 6. Notes

- **6.1** Output loading should not exceed 3500W/16A.
- **6.2** Before using the timer it is recommended to plug the unit into a power mains for a few hours to charge the battery of the timer.
- **6.3** The tolerance of the timer is 2 minutes per month.
- **6.4** 'Summer time' can be added to the timer (optional, please contact your dealer).
- **6.5** This timer is 24-hour display. A 12- hour version is available, please contact your dealer.

This device is classified as type **I.B.S** according to **EN60730-2-7.** 

This device is suitable for use in normal pollution situations.

Johannesburg Tel: (011) 879-6600 Fax: (011) 879-6603 Cape Town Tel: (021) 594-7100 Fax: (021) 594 7130

Durban Tel: (031) 492-0481 Fax: (031) 569-9909 Port Elizabeth Tel: (041) 408-2400 Fax: (041) 453-0336





